CV_KH2113_E266_LB6.qxd 13.08.2007 13:32 Uhr Seite 1

KH 2113

GB IE CY

PROFESSIONAL **HAIR DRYER**

Operating Instructions

KOMPERNASS GMBH · BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: KH2113-07/07-V2

CV_KH2113_E266_LB6.qxd 13.08.2007 13:32 Uhr Seite 4

IB_KH2113_E266_LB6.qxd 09.08.2007 13:15 Uhr Seite 3

List of Contents Page

Safety instructions	4
Intended Use	5
Delivery Contents	5
Description of the appliance	5
Operation	5
Drying and styling hair	5
Cleaning	6
Troubleshooting	6
Disposal	6
Technical data	7
Warranty and Service	7
Importer	7

Read the operating instructions carefully before using the appliance for the first time and preserve this booklet for later reference. Pass the manual on to whomsoever might acquire the appliance at a later date.

IB_KH2113_E266_LB6.qxd 09.08.2007 13:15 Uhr Seite 4

Professional Hair Dryer KH2113

Safety instructions

⚠ Danger of electrocution!

- Connect the Professional Hair Dryer only to correctly installed and earthed power sockets with a mains voltage of 230-240V at ~50 Hz.
- Under no circumstances may the Professional Hair Dryer be submerged in fluids, or fluids be permitted to enter the housing of the Professional Hair Dryer. Do not expose the appliance to humidity and do not use it outdoors. Should liquids enter the housing, unplug the appliance from the power socket immediately and arrange for it to be repaired by a qualified technician.
- Never use the appliance near water, particularly not near sinks, baths or other vessels . The proximity of moisture presents a danger, even when the appliance is switched off. After use, always remove the plug from the power socket. As additional protection, the installation of a faulty-current protection unit with an activation power rating of not more than 30 mA is recommended for the power circuit in the bathroom. Ask your electrician for advice.
- Remove the plug of the Professional Hair Dryer from the power socket in the event of functional irregularity and before cleaning the appliance.
- To disconnect, pull only on the plug itself, not on the cable.
- Do not wrap the power cable around the Professional Hair Dryer and protect it from damage.
- To avoid injury, arrange for damaged power cables to be exchanged by specialists before re-using the appliance.
- Do not pinch or squeeze the power cord and lay it in such a way that no one can tread on or trip over it.
- Do not use extension cables.
- Never touch or handle the Professional Hair Dryer, the power cable or plug with wet hands.
- Immediately separate the Professional Hair Dryer from the power source after use. The appliance is completely free of electrical power only when unplugged.
- You are not permitted to open the housing of the Professional Hair Dryer or carry out repairs to it. Should you do so, the safety of the device may be compromised and the warranty becomes void. The Professional Hair Dryer is to be serviced and repaired by authorised specialists only.

⚠ Danger of fire and burns

- Do not allow individuals (including children) to use the appliance whose physical, sensorial or mental abilities or lack of experience and knowledge hinder their safe usage of it if they have not previously been supervised or instructed in its correct usage.
- Tell children about the appliance and its potential dangers so that they do not play with it.
- When it is switched on, never lay the Professional Hair Dryer down or leave it unsupervised.
- Never place the Professional Hair Dryer close to sources of heat and protect the power cable against potential damage.
- Should the Professional Hair Dryer be dropped or sustain any damage, it may no longer be used. Arrange for the appliance to be checked and possibly repaired by qualified technicians.
- You are not permitted to open the housing of the Professional Hair Dryer or carry out repairs to it. Should you do so, the safety of the device may be compromised and the warranty becomes void. The Professional Hair Dryer is to be serviced and repaired by authorised specialists only.

IB_KH2113_E266_LB6.qxd 09.08.2007 13:15 Uhr Seite 5

- Do not cover the air suction grill while operating the appliance. Clean it at regular intervals.
- The Professional Hair Dryer becomes hot during use. Hold it only by the grip when it is hot.

Intended Use

The Professional Hair Dryer is intended only for the drying and shaping of human hair, under no circumstances is it to be used for wigs and hairpieces made of synthetic material. You may use it exclusively in domestic households. Pay heed to all of the information in this operating manual, especially the safety instructions.

Delivery Contents

- Professional Hair Dryer KH 2113
- Styling Jet
- Finger Diffusor
- Operating manual

Description of the appliance

❶ Styling Jet
❷ Filter element
❸ Air suction grill
❹ Suspension lug
❺ Blower level switch (2 levels)
❻ Heat level switch (3 levels)
❼ Cool level switch ("Cool-Shot")
❽ Finger Diffusor

Operation

➪ Insert the plug into the wall socket.
➪ Switch the Professional Hair Dryer on with the blower level switch ❺.

The Professional Hair Dryer is fitted with two function switches. With these you can separately select the strength of the air flow (Blower switch ❺) and the amount of heat (Heat level switch ❻):

Blower levels
0 The Professional Hair Dryer is switched off
1 reduced air flow
2 full power air flow

Heat levels
1 Cold air flow
2 Low heating level
3 High heating level

With the cool level switch "Cool-Shot" ❼ you can produce a cooler air flow with every combination of blower and heat levels.

➪ Switch the appliance off after use, in that you place the blower switch ❺ into position "0". Then remove the plug from the wall socket.

Drying and styling hair

➪ To quickly dry hair, we recommend first of all using a high blower and heater setting for a short period. Afterwards, place the settings at a lower level to shape and form the hair.

With the enclosed styling jet ❶, which can be turned into all positions, you can use the air flow directly for styling.

IB_KH2113_E266_LB6.qxd 09.08.2007 13:15 Uhr Seite 6

If you wish wish to dry your hair particulary gently, or for the so-called "air-dryed permanent wave", use the finger diffusor ❽.

➪ For this, first of all remove the styling jet ❶, then replace it with the finger diffusor.
➪ Before you comb your hair out allow it to cool, so that the styling retains its form.
➪ For cooling the hair you can use the switch "Cool-Shot" ❼ or level 1 of the blower switch ❻ settings.

⚠ **Attention!**
First pack and transport the Professional Hair Dryer when it has completely cooled down. Otherwise, it could damage other items.

Cleaning

⚠ **Danger of electrical shock**
Before cleaning the Professional Hair Dryer, always remove the plug from the mains wall socket.

Cleaning the housing

➪ To clean the housing, use a soft cloth moistened with a mild soapy solution.

Cleaning the air suction grill and the filter element

⚠ **Fire hazard!**
Clean the air suction grill ❸ and the filter element ❷ at regular intervals with a soft brush.

➪ Fold out the air suction grill ❸ to the rear.
➪ Clean the filter element ❷ and the openings of the air suction grill ❸ with a soft brush.
➪ Replace the filter element ❷ and close the air suction grill ❸.

⚠ **Danger of electrical shock**
Before using the Professional Hair Dryer again after cleaning, it must be completely dry.

Troubleshooting

Should your Professional Hair Dryer not function as expected, first remove the plug from the wall socket and allow the appliance to cool down for a few minutes. The appliance is fitted with an overheating protector! Should the appliance still not function when cooled down, consult the service.

Disposal

Do not dispose of the appliance in your normal domestic waste.

Dispose of the appliance through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre.

Dispose of the packaging materials in an environmentally responsible manner .

IB_KH2113_E266_LB6.qxd 09.08.2007 13:15 Uhr Seite 7

Technical data

Mains voltage:	230-240V ~ 50Hz
Rated output:	2000 W
Protection class:	II/⧈

Warranty and Service

This appliance is guaranteed for 3 years from the date of purchase. It has been carefully produced and meticulously checked before delivery. Please keep your receipt as proof of purchase. Contact your service centre by telephone in case of questions pertaining to the warranty.
Your goods can be transmitted free of cost only in this manner.

The warranty covers only material or manufacturing faults, not normal wear or damage to fragile parts such as switches or rechargeable batteries. The appliance is intended solely for private, not commercial, use. If this product has been subjected to improper or inappropriate handling, abuse, or
interventions not carried out by one of our authorised sales and service outlets, the warranty will be considered void. This warranty does not affect your
statutory rights.

(GB) **DES Ltd**
Units 14-15
Bilston Industrial Estate
Oxford Street
Bilston
WV14 7EG
Tel.: 0870/787-6177
Fax: 0870/787-6168
e-mail: support.uk@kompernass.com

(IE) **Kompernass Service Ireland**
c/o Irish Connection
41 Harbour view
Howth Co. Dublin
Tel: 087-99 62 077
Fax: 18398056
e-mail: support.ie@kompernass.com

Importer

KOMPERNASS GMBH
BURGSTRASSE 21
D-44867 BOCHUM
www.kompernass.com